

BH05200 USER MANUAL
GUIDE DE L'UTILISATEUR BH05200
MANUAL DEL USUARIO BH05200

DUAL BAY CHARGER
CHARGEUR DOUBLE BAIE
CARGADOR DE BAHÍA DOBLE

© 2019 TECHTRONIC FLOOR CARE TECHNOLOGY LIMITED. ALL RIGHTS RESERVED. CHARLOTTE, NC 28262 800-406-2005

IMPORTANT SAFETY INSTRUCTIONS
SAVE THESE INSTRUCTIONS

When using this charger, basic precautions should always be followed, including the following:
READ ALL INSTRUCTIONS BEFORE USING THIS CHARGER

WARNING:

To reduce the risk of fire, electric shock, damage or injury:

- Dry location use only.
- For use only with ONEPWR™ Batteries.
- Do not use with damaged cord or plug.
- Do not pull or carry by cord.
- Do not unplug by pulling on cord.
- Do not handle plug or charger with wet hands.
- Follow all charging instructions.
- Do not disassemble charger.
- Follow all mounting instructions.


WARNING! RISK OF FIRE, PROPERTY DAMAGE, AND INJURY. NEVER EXPOSE YOUR BATTERY PACK OR CHARGER TO WATER, MOISTURE, OR FLUIDS...
- Wear appropriate personal protective equipment.
- Place your exposed battery pack in a large bucket.
- Leave the battery pack(s) in the bucket filled with tap water.

ASSEMBLY

WARNING! To prevent risk of strangulation, fire, or shock, route cord properly, avoiding loops, is out of the reach of children, and where they cannot get snagged or pulled.

WARNING! If you hit metal, stop immediately and contact an electrician.

- 1. Locate a wall stud with a stud finder to mount charger where, when mounted, it can be plugged into an outlet that is easily accessible and out of the reach of children.
2. Use only the power cord supplied with the kit.
3. Remove the charging indicator plate, as shown in Figure 1, and align the mounting holes with the center of the stud.
4. Hold charger to wall, fit and tighten the top screw, then the bottom screw (2).
6. Place the reversible charging indicator plate back on the charger. IMPORTANT: Always ensure the batteries are secured into place.



OPERATION

APPLICATIONS

You may use this product for the following purpose:
- Charging ONEPWR™ Lithium Ion Batteries.

CHARGING (Figure 2)

- Charge the battery fully before first use. This will take up to 4 hours.
- Make sure the power supply is normal household voltage, 120 volts, AC only, 60 Hz.
- Do not place the charger in an area of extreme heat or cold.
- Plug the charger into a power outlet.
- Attach the battery pack to the charger by aligning the ribs on the battery pack to the grooves in the charger.
- When charging, the lights on the battery will illuminate to show the state of charge.
- When the charge is complete the lights on the battery and charger will turn off.




Figure 2
figure 2
Figura 2

MAINTENANCE

- Do not disassemble charger. Do not modify or attempt to repair the charger. This charger has no serviceable parts. Call Customer Service at 1-888-406-2005.

Table with 5 columns: MODE, BATTERY PACK, RED LED ON CHARGER, WHITE LED ON CHARGER, ACTION NEEDED. Rows include POWER, TESTING (HOT and COLD Battery Pack), DEFECTIVE, CHARGING, and FULLY CHARGED.

COMPATIBLE BATTERY PACKS

Table listing compatible battery packs with columns for Battery (2.0 Ah, 3.0 Ah, 3.0 Ah MAX, 4.0 Ah, 4.0 Ah MAX, 6.0 Ah) and Model # (BH15020, BH15030, BH25030, BH15240, BH25040, BH15260).

SERVICE INFORMATION & LIMITED WARRANTY FOR ONEPWR BATTERIES

THREE YEAR LIMITED WARRANTY (DOMESTIC USE)

If this product is not as warranted, contact TTI Floor Care North America Customer Service at 1-800-406-2005. Please have available the proof of purchase and model number for the warranted product.

WHAT THIS LIMITED WARRANTY COVERS: This limited warranty provided by Royal Appliance Mfg. Co., doing business as TTI Floor Care North America (referred to hereafter as "Warrantor") applies only to products purchased in the U.S. (including its territories and possessions), a U.S. Military Exchange, or Canada. When used and maintained in normal household use and in accordance with the User Manual, your ONEPWR charger is warranted against original defects in material and workmanship for three years from the date of original purchase (the "Warranty Period").

WHO THIS LIMITED WARRANTY COVERS: This limited warranty extends only to the original retail purchaser, with original proof of purchase from Warrantor or an authorized dealer of Warrantor products, in the U.S., U.S. Military Exchanges, and Canada.

WHAT THIS LIMITED WARRANTY DOES NOT COVER: This warranty does not cover use of the product in a commercial operation (such as maid, janitorial, and equipment rental services, or any other income-generating activity); improper maintenance of the product; the product if it has been subject to misuse, negligence, neglect, vandalism, or the use of voltages other than that on the data plate of this product. This warranty does not cover damage resulting from an act of God, accident, owner's acts or omissions, service of this product by other than Warrantor or a Warrantor authorized service provider (if applicable), or other acts beyond the control of Warrantor.

OTHER IMPORTANT TERMS: This warranty is not transferable and may not be assigned; any assignment made in contravention of this prohibition is void. This warranty shall be governed and construed under the laws of the state of North Carolina. The Warranty Period will not be extended by any replacement of batteries or parts or repair performed under this warranty.

THIS WARRANTY IS THE EXCLUSIVE WARRANTY AND REMEDY, AND ALL EXPRESS AND IMPLIED WARRANTIES OTHER THAN THE LIMITED WARRANTY SET FORTH ABOVE, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED. IN NO EVENT WILL WARRANTOR BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND OR NATURE TO OWNER OR ANY PARTY CLAIMING THROUGH OWNER, WHETHER BASED IN CONTRACT, NEGLIGENCE, TORT, OR STRICT PRODUCTS LIABILITY OR ARISING FROM ANY CAUSE WHATSOEVER. TO THE EXTENT PERMITTED BY APPLICABLE LAW, NO WARRANTIES THAT ARISE BY OPERATION OF LAW, IF APPLICABLE, SHALL EXCEED THE DURATION OF THE LIMITED WARRANTY PROVIDED HEREIN.

Some states do not allow the exclusion or limitation of incidental or consequential damages, disclaimers of implied warranties, or limitations on the duration of implied warranties, so the above exclusions, disclaimers, and/or limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

CONSIGNES DE SÉCURITÉ IMPORTANTES
CONSERVEZ CES INSTRUCTIONS

Lorsque vous utilisez ce chargeur, veuillez toujours respecter entre autres les consignes de sécurité élémentaires suivantes :
VEUILLEZ LIRE TOUTES LES INSTRUCTIONS AVANT D'UTILISER CE CHARGEUR.

AVERTISSEMENT

Pour réduire le risque d'incendie, de décharge électrique, de dommage ou de blessure :


- Pour une utilisation dans un endroit sec uniquement.
- Utilisez uniquement avec les piles ONEPWR™.
- N'utilisez pas l'appareil lorsque le cordon ou la fiche est endommagé.
- Ne tirez pas et ne transportez pas le chargeur par son cordon.
- Ne débranchez pas le chargeur en tirant le cordon.
- Ne manipulez pas la fiche ou le chargeur avec des mains mouillées.
- Ne démontez pas le chargeur.
- Suivez toutes les instructions de montage.

ASSEMBLY

AVERTISSEMENT! Pour éviter tout risque d'étranglement, d'incendie ou de choc électrique, acheminez le cordon correctement, en évitant les boucles, hors de la portée des enfants et où ils ne puissent se faire accrocher ou tirer.

AVERTISSEMENT! Si vous touchez du métal, arrêtez immédiatement et contactez un électricien.

- 1. Localisez un poteau mural avec un détecteur de poteaux pour monter le chargeur.
2. Utilisez uniquement le cordon d'alimentation fourni avec le kit et enroulez l'excès de longueur de cordon autour de l'enrouleur de cordon situé à l'arrière du chargeur.
3. Retirez la plaque indicatrice de charge, comme illustré à la figure 1, et alignez les trous de montage avec le centre du goujon.
4. Tenez le chargeur au mur, montez et serrez la vis supérieure, puis la vis inférieure (2).
5. Remplacez la plaque indicatrice de charge réversible sur le chargeur.
6. Branchez le chargeur. En cas de problème, retirez la fiche de la prise murale.
7. Rangez les batteries en les faisant glisser dans le chargeur et en les poussant vers le bas pour les sécuriser.



AVERTISSEMENT! RISQUE D'INCENDIE, DE DOMMAGES MATÉRIELS ET DE BLESSURES. NE JAMAIS EXPOSER VOTRE BLOC-PILES OU VOTRE CHARGEUR À DE L'EAU, DE L'HUMIDITÉ OU DES LIQUIDES. Y COMPRIS, SANS S'Y LIMITER, DES LIQUIDES CORROSIFS OU CONDUCTEURS, NI LAISSER LES LIQUIDES S'INFILTRER DANS CES ARTICLES. Les liquides corrosifs ou conducteurs, comme l'eau salée, le chlore, certains produits chimiques industriels, les agents de blanchiment, les produits contenant des agents de blanchiment, etc., peuvent causer un court-circuit dans le bloc-piles. Si le bloc-piles est exposé à un liquide corrosif ou conducteur, ne pas tenter de l'utiliser ou de le charger. Effectuer immédiatement les étapes ci-dessous :

UTILISATION

UTILISATIONS

Ce produit peut être utilisé aux fins suivantes :
- Charger les piles au lithium-ion ONEPWR™.

CHARGEMENT (figure 1)

- Effectuez une charge complète de la pile avant la première utilisation. La durée de charge est d'environ 4 heures.
- Assurez-vous que l'alimentation électrique a une tension résidentielle normale de 120 V en c.a.
- Ne placez pas le chargeur dans une zone de chaleur ou de froid extrêmes.
- Branchez le chargeur dans une prise électrique.
- Fixez le bloc-piles au chargeur en alignant les rainures en saillie sur le bloc-piles avec les rainures du chargeur.




Figure 1
figure 1
Figura 1

