



QUICK START GUIDE

SMARTWASH PET COMPLETE AUTOMATIC CARPET CLEANER

961003488

GETTING STARTED

1



Attach Clean Water Tank & Handle.

2



Pinch tabs on SpotChaser Tank and pull downwards. Fill with HOOVER® SpotChaser Wand Formula and push it back into Handle.

USE RECOMMENDED
HOOVER® SOLUTIONS

PRO TIPS

Do not mix solutions with water when filling Solution Tank.

Allow SpotChaser solution to soak into stains for 5min before cleaning carpet.

For best results, use only HOOVER® brand solutions.

3



Remove Solution Tank, fill & reinsert.

USE ONLY RECOMMENDED
HOOVER® SOLUTIONS

4



Remove Clean Water Tank, fill with warm water & reinsert.

Quarter turn and pull to remove cap

HOW TO USE: SPOTCHASER PRETREAT WAND



1 Press button to release.



2 Aim at stain and press button.



3 Reinsert Handle.

PRO TIPS

Keep SmartWash in the upright position when removing the Pretreat Wand.

Maintenance Tip:
Empty tanks after each use and allow to air dry.

When Dirty Water Tank needs to be emptied, there will be a change in operation sound.
To maintain proper suction, empty Dirty Water Tank promptly.


HOW TO USE: MAIN UNIT



1 Use pedals to operate.



2 To clean carpets, slowly push forward and pull back.



3 Lift handle on Dirty Water Tank to remove.

PRO TIPS

To clean Filter:
Follow instructions labeled on the back of Dirty Water Tank.

For best results:
Slowly operate unit on forward and backward strokes.

For best performance:
Complete system care after each use. See user manual for more info.