




# POWER SCRUB™ XL CARPET & UPHOLSTERY CLEANER



## QUICK START GUIDE

### GETTING STARTED




1  
Attach Handle.




2  
Fill Tank with Water up to MAX line located on side of the tank. Follow steps on solution bottle to add the appropriate amount of solution to tank.

### HOW TO USE: MAIN UNIT



1  
Use pedals to operate.



2  
Slowly Push forward and squeeze trigger to wash. Release Trigger and slowly pull unit back to Dry carpet. Repeat and move to new section.

## HOW TO USE: ABOVE FLOOR



1 Hose Attachment.



2 Tool Attachment.



3 Spray / Scrub.


## HOW TO USE: CLEANING AND MAINTAINING



1 Remove Dirty Water Tank.



2 Pull to Remove Nozzle Cover.



3 To Remove Brushes, press both tabs on side of foot. To Reinsert Brushes push them back in place until you hear a click.



4 Reinsert Brushes and Press Firmly until Latches Lock.

## HOW TO USE: QUICK CLEAN MODE\*

\*Available for select models only.



Quick Clean Mode



Deep Clean Mode

1 To Engage Quick Clean Mode, Turn Knob Counter-Clockwise until engaged. Return to Deep Clean Mode by Turning knob Clockwise to Starting Position.



For Frequently Asked Questions and to Register your new product, scan here!